

Instruction for replacement of Ø14mm forestay Furlex 400 S and 400 H.

1. The Furlex-system must be dismantled from the boat prior to this operation.
See chapter Dismantling in the manual. Page 46 in 595-116 (400S) and page 28 in 595-119 (400H)
2. After opening the wire terminal, pull the wire out from the top.
3. Remove the top-guard.
4. Cut of a piece of the top extrusion acc. to the figure.
5. Reassemble the top-guard.
5. Measure the old forestay and mark the cutting measurement on the new stay. **Do not cut the stay yet.**
6. Assemble the new forestay. **See page 18 in 595-116 and page 18 in 595-119.** Replace the old wedge with the new one supplied with the forestay.

