

RBB60/80/100/130 -Soft attachment

The Seldén Roller Bearing Blocks are designed to be used with either a spliced line or a line with a knot. Attaching the line to the block is straightforward:

1. Pass the line through the central hole in the block.
2. Make a splice or tie a secure knot to fasten the line.

To prevent the block from rotating around the line, it is recommended to secure the line using a thin locking line. Follow these steps:

1. Thread the locking line through the holes at the top of the block and around the main line.
2. Make 2–3 turns with the locking line.
3. Tighten the locking line gently—do not overtighten.

