

# Backstay flicker

## - gives the mainsail space to move

The backstay flicker is a glass fibre rod fitted to the head box on a fractional rig with swept spreaders. It lifts up a wire or rope backstay to allow for free passage of a full roach mainsail.



595-820-E 2023-01-19



*The backstay flicker comes complete with fasteners and backstay block.*

## Complete kit with fasteners and instruction for assembly

Art. No.	Batten length, mm	Boat size, ft
511-120-01	1200	< 30 fot
511-121-01	1400	30-37 fot
511-123-01	1800	37-43 fot