Replacement of Tele-pole locking knobs

Kit includes locking knobs, spring, rivets and drill bit.

Tools needed: Power drill, ø2.5mm plunger, hammer and pop rivet gun.

This instruction applies to:

Tele-pole size	Kit Part no.
60/48	308-109-01R
72/60	308-109-02R
84/72	308-111-01R


1.

Drill out the pop rivets and remove both end fittings.



2.

Push in the inner tube into the outer tube until the inner end of the inner tube exits the outer tube. Take care not loosing the knobs and spring.



3.

Replace the spring and locking knobs. Push the inner tube back into the outer tube.



4.

Assemble the end fittings. Use the correct pop rivets acc. to table. Punch out the rivet balls after riveting. Empty the pole of any rivet balls through the plunger holes.

Tele pole	Inner end	Outer end
60/48	Ø4.8x12.7	Ø4.8x16.5
72/60	Ø4.8x16.5	Ø4.8x12.7
84/72	Ø4.8x12.7	Ø4.8x16.5

